



DataView
Data Acquisition Software

Operation Manual
Version 1.4.3

***Newage Testing Instruments, Inc.** reserves the right to alter designs, materials, and specifications when conditions warrant, without notice.*

***Newage Testing Instruments, Inc.** makes no representations or warranties, either expressed or implied, with respect to this publication and accompanying software and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. This publication and accompanying software are sold "as is", and **Newage Testing Instruments, Inc.** will in no event be liable for direct, indirect, incidental, or consequential damages resulting from any defect, error, or failure to perform.*

The software described in this publication is furnished under license and may only be used in accordance with the terms of such license.

***DataView™** is a trademark of **Newage Testing Instruments, Inc.** Windows™ is a trademark of Microsoft Corp.*

Copyright© by Newage Testing Instruments, Inc. All rights reserved. This publication is protected by copyright, and all rights are reserved. No part of it may be reproduced in any form without express written consent from Newage Testing Instruments, Inc.

Table of Contents

1. Basic Operation	4
1.1. Introduction	4
1.2. Package Includes	4
1.3. System Requirements	4
1.4. Hardware Setup	4
1.5. DATA VIEW Security Lock Installation	5
1.6. Installing the DataView Program	6
1.7. Initial Start-up	8
2. DataView Toolbar Options	10
2.1. New	10
2.2. Open an Existing File	14
2.3. Save	14
2.4. Export	15
2.5. Admin	16
2.6. Comm Setup	18
2.7. Verification or Calibration	20
2.8. Statistics	22
2.9. Print Preview	22
2.10. Print	23
2.11. Help	26
3. Mode of Operations	26
3.1. Online Mode:	26
3.2. Offline Mode	27
3.3. Operations on Test results	27
3.4. Add	28
4. Contact Information	31

1. Basic Operation

1.1. Introduction

Welcome to the Newage Testing Instruments' DataView™ Application. This is Windows™ based data acquisition software for all makes and models of digital hardness testing equipment. This software is developed to enhance the capabilities of your hardness testers by allowing you to transfer test results directly to a PC for real time, on-screen data management.

It is assumed that the operator has a basic understanding of Windows. If you are unfamiliar with how to use a PC, please refer to your Windows manual for instructions.

The DataView program is file based. All setup parameters (such as hardness scale, tolerance limits, part information, etc.) are saved with the individual file they are associated with.

1.2. Package Includes

The complete DataView package consists of :

- 1 - DataView CD
- 1 - Serial RS232 Cable or RS232-to-USB Cable
- 1 – License Dongle
- 1 - Operation Manual

1.3. System Requirements

The following Windows platforms are supported:

- Windows 7
- Windows XP Home or Professional (SP3)
- Windows Vista (SP1)
- Windows Server 2003 or 2008

Intel Pentium or compatible, 1.4GHz minimum (2GHz+ recommended)

256 MB RAM

VGA color monitor (1024x768 or higher resolution recommended)

1 Serial or USB port recommended

Hardness Tester: RS232 output with data string in ASCII format.

1.4. Hardware Setup

Make sure that the power is turned off on both the hardness tester and the connecting PC. Connect the hardness tester to the PC with the serial cable.

- 1) Plug the serial connector into the RS232 port on the hardness tester.
- 2) Connect the 9 or 25 pin connector into the COM 1 or COM 2 port on the back of the PC. The Security dongle must be connected to USB Port in order for the software to work (Figure 1.4.A). If the Security dongle is not connected, the DataView application will run in Demo mode.

Note: You can use RS232 to USB converter to connect Hardness device and computer if your computer doesn't support RS232 9 pin/25 pin COM Port (Figure 1.4.B).



Figure 1.4.A
Back View of PC

9 Pin RS232 Port.
COM Port (COM1)

25 Pin Parallel COM Port. Printer/
Security Dongle/ Hardness Device

USB Port



Figure 1.4.B
Back View of PC

1.5. DATA VIEW Security Lock Installation

1.5.1 USB Key

Prerequisite:

- Make sure that you are using same Operating System as mentioned in System Requirement section.
- Install the Security Dongle driver software **BEFORE** the key is plugged in.

If the system has a USB Security Lock (Figure 1.5.A) , the driver software must be installed before the key is plugged in; if the key is plugged in before the software is installed, windows installs the default drivers and the key does not work. The Software for the USB Security Key is installed as part of the Installation; simply run the setup.exe program from the DataView CD and Reboot the computer BEFORE inserting the key.

After Rebooting, insert the Key; Windows will display USB Key found. If not, windows will display a dialog and follow below steps:

- a. Select the Install Software Automatically Option, click Next
- b. At the Compatibility Test Dialog Box click Continue Anyway
- c. Click Finish

Figure 1.5.A
Back View of PC




1.6. Installing the DataView Program


- 1. Insert the DataView CD.
- 2. Click on Setup.exe file. This will install .NET framework 4.0 followed by DataView Application.

Steps:


- a. Click Next




- b. Select the appropriate folder for installation and click Next




c. Click Next to Install the application



d. Click Close to once the installation is completed.




3. DataView.exe shortcut file appears in Desktop. Click on the shortcut to launch the application.



4. Installed application contains sample test files named Sample1.xml, Sample2.xml, Sample3.xml, SampleCSV1.csv, SampleCSV2.csv, SampleCSV3.csv

1.7. Initial Start-up

1. Double-click the DataView.exe shortcut from the desktop.
2. Application displays Initial “DataView Setting” Dialog.



3. Select appropriate Communication and File Option.


Communication option:

- a. **Online:** Enables user to select appropriate COM port from which Hardness device can communicate with DataView application.
- b. **Offline:** Enables user to enter offline data manually.

File Option:

- a. **New File:** User can select new file to save the test results.
- b. **Open existing File:** Enables user to select existing stored file. All the subsequent data will be stored in the same opened file.

Note: Once the program has been used, it will open to show the most recent file that was in use.



Measuring Conditions


X-Bar & R Chart Panel

Current Test Result Panel

Toolbar

History Data Panel

Histogram Panel



DataView Application Window


2. DataView Toolbar Options




2.1. New

Select New to create new Test Result file.

- a. On clicking this option, a file dialog will be displayed to enter the valid filename.




- b. Type the file name and click Save.
- c. You will then be prompted for “Measuring Conditions”.



Settings in this dialog are as follows:

Scale: Select Primary hardness scale. This scale should be same as the scale in the Hardness device.

Used Defined/Custom Scale: Clicking  button which is next to primary scale allows user to add new scale. *Converted scales* have no effect if user adds/selects custom scale.

Converted Scale: Select the scale in *Converted Scale* if you would like the test result automatically converted to another scale.

Average Group: This is useful when doing multiple tests on an individual part to obtain an average hardness value. The averaged reading is stored in the data base, along with the individual test results, however, only the averaged hardness value is used in the statistical calculations. Select the Group Size and enter the desired number from 0 to 50. A setting of “0” or “1” essentially deactivates the average function.

When *Group Size* is greater than 1, X-Bar & R Charts windows appears somewhat differently. In the History Data Panel, all the hardness values are displayed under *Reading* column and the averaged hardness value displayed in respective selected *Scale* column. In the *Export/Print* Report the individual values also appear. In the X-Bar & R Chart window the range of data is displayed by a vertical line extending from the result graphically showing the range of the individual components of the averaged value.

NOTE: Once data has begun being collected, the number of tests being averaged cannot be changed. A new file needs to be setup with a different average size.

No	Date Time	Readings	HRC	Status	Part Number	Note
1	7/14/1999 4:48:00 PM	56,56,56,56,56	56	Pass		
2	7/14/1999 4:49:00 PM	56,56,59,59,59	57.8	Pass		
3	7/14/1999 5:03:00 PM	55,57,59,64,44	55.8	Pass		
4	7/14/1999 5:03:00 PM	44,44,44,44,44	44	Low		
5	7/15/1999 10:21:00 AM	55,55,55,55,55	55	Pass		

Figure 1.4.B
History Data on
Group Size > 1




Figure 1.4.B
Histogram on
Group Size > 1

SNo	DateTime	HRC	Readings	Status	Note
2	7/14/1999 4:48:00 PM	56	56,56,56,56,56	OK	
3	7/14/1999 4:49:00 PM	57.8	56,56,59,59,59	OK	
10	7/14/1999 5:03:00 PM	55.8	55,57,59,64,44	OK	
11	7/14/1999 5:03:00 PM	44	44,44,44,44,44	LO	
12	7/15/1999 10:21:00 AM	55	55,55,55,55,55	OK	

Figure 1.4.B
Report on Group
Size > 1

Tolerance: Enter the *Tolerance* level. The program uses these settings for statistical calculations and for HI, LO, and Pass indications for individual test results. The X-Bar & R Chart uses these settings to plot the High and Low test results as red points on the graph; acceptable test results are plotted as green points. You may also set a Low Warning and High Warning number. By setting the Low and High Warning numbers, 5 groups of readings are created, helping in sorting parts. The Warning numbers are not used in statistical calculations, but will appear next to the individual test results and on the X-

Bar/R Chart as grey points on the graph. Select the desired warning and tolerance values.


NOTE: Entering High and Low values of “0” will deactivate the Tolerance function. All readings will then be recorded without any tolerance indication although the calculated process limits will still appear in reports.

Minimum Thickness: Use this to have the minimum thickness requirement displayed for the current test result per Tables A5.1-A5.4 in ASTM E 18. Choose Off to deactivate the Minimum Thickness function, or Inches or Millimeters to activate it. The program will display the Minimum Thickness value for the current test result after each test is taken. The minimum thickness value appears on Result Panel.

Roundness Correction (For use with Rockwell Scales Only): Use this function when testing on cylindrical surfaces to automatically add the round correction factor to the test result per Tables A6.1-A6.4 in ASTM E 18. Choose *Inches* or *Millimeters* to activate the Round Correction function, or *Off* to deactivate it. Set the desired *Diameter*. The selected round correction diameter appears on the bottom left of *Result Panel*, but there is no other indication that the results have been altered by the Round Correction factor.

- d. Clicking Apply displays *Part Information* dialog. This information can be used to keep track of Part Number, Description, Order Number, etc., related to this test result file. These headings will appear on exported/print reports. Data entry is not mandatory.

You can add new Part Information by clicking *Add*. This will add an entry in the list where you can edit or add desired information. You can also remove the entry, by selecting it and clicking *Remove*. On clicking *Close* application main window appears to perform the actual operations.




Note: You can modify the Part Information at any time of DataView execution.

2.2. Open an Existing File

Open existing Test Result file stored in disk.

- a. On clicking this option, a file dialog will be displayed to load existing file.




- b. Choose the desired file to open by highlighting it from the list. You can choose either .CSV file or .XML file.
- c. Click *Open*. All the settings and test result will be displayed on main window.

2.3. Save As

Save the running test results to an XML or CSV file.

- a. On clicking this option, a file save dialog will be opened.




- b. Specify the desired file name and click *Save*.


2.4. Export

Allow user to save/export the test results in different format. The supported formats are PDF, Microsoft Word, Microsoft Excel and Tiff Format

- a. On clicking this, a dropdown menu appears.



- b. Selecting one among the 4 options displays *Export Options*.




Selected options like *Part Information*, *Result Information*, and *Test Results* etc. in *Export Option* will be included in the exported file. Company Information will be appeared in the exported file if user specify in the *Export option* dialog. On clicking button “...” in *File Option*, you can specify the File name of save/exporting file.


2.5. Admin

Allow Administrator to enable or disable set of operations to the operator who uses the application. This will avoid operator performing unwanted operations such as removing or modifying failed test results.


- a. On clicking the *Admin* button, a dialog will appear.



- b. By default, there will not be a password. You need to click *Change Password* to change the password.



- c. Click *Apply* will change the password of admin.
- d. You can now enter the password in *Password* field and click *Validate*. All the possible options are enabled.




- e. Enable or disable desired options for User and click *Apply*.
- f. Main Window will disable respective options for the current user.

2.6. Comm Setup

Used to control the communications between the PC and the hardness testers. It allows for adjustment of Connecting Port selection, Baud Rate, Parity, and Data Bits. Consult your hardness tester manual for its RS232 output specifications.

- a. On clicking this, a dropdown menu appears.




- b. On clicking *Mode*, it will allow user to select mode of operation. There are two types of modes:

Online: DataView communicates with the Hardness device to receive hardness readings. Also this will be useful in *Verification Mode* for auto calibrating the device.

Offline: DataView run in a standalone mode without connecting the device. User can manually enter the data.


(For detailed information please refer section 3.0)




You can also select this option from bottom right of the *Status bar*.



- c. Option *Port Settings* can be used when the *Mode* is *Online*. This allow user to select appropriate COM port to which Hardness device is connected, through Serial or USB port. If the user select mode *Online* first time then *Port Settings* will appear automatically.



- d. *Forward Output* can be used for forwarding the test results to external device(s) through RS232 port. One can send the data to external device by selecting suitable COM port and settings, and checking/enabling *Forward Output* option. One can add the forward-data by clicking *Add* option and selecting the test result.



Sample Preview shows sample forward-data packet.


2.7. Verification or Calibration

This function allows you to perform periodic calibration verification of your hardness testers according to parameters which you program in. The Verification Mode can be setup to automatically require verification of your hardness testers at predetermined

intervals. After the verification has been run, the program will confirm the tester’s compliance with your programmed parameters and print out a Verification Certificate, or notify you if the equipment is out of spec.

There are 6 user assignable parameters to setup for running verifications: Tester, Scale, Range, ASTM Spec, Test Block Description, and Schedule Verification (Every interval)

- a. Select the Verification from Toolbar. Verification Setup dialog appears:



Tester - Create a list of the testers you will be verifying using the Manufacturer Name, Model Number, and Serial Number. The program will then keep a record of each unit’s verification history.

You can create a new tester just by editing the fields under *Tester*. Already stored tester data will be appeared by clicking the respective drop down box.

Note: For verification all the *Tester* field such as Manufacturer, Model, Serial no is mandatory.

Scale and Range: Choose the *Scale* you wish to verify from the list. Select the range from *High*, *Medium*, and *Low*.

Acceptance Criteria: Designate the *Maximum Deviation* and *Maximum Range* allowed by the ASTM Spec you need to conform to. As per the ASTM spec Maximum Deviation refers to “**Error**” and Maximum Range refers to “**Repeatability**”.

Test Block Description: Designate the *Hardness (Block) Value*, *Serial Number*, *Block Manufacturer* and *Average Group Size* of the Test Block. Enter the nominal value of block and Average Group Size. Also enter *Serial No.* and *Manufacturer Name*.

Schedule Verification: Use this function to have the program automatically launch into the Verify Mode at regular intervals.


1. Assign the time frame in either Hours or Days by clicking on the appropriate option.
 2. Enter the interval in *Verify Every* field.
- b. You may run a verification at this time by clicking on the Start Verification button, OR click on OK to save the setup to run at the designated time interval. *Verify Data* allow user to view stored verify data which is calibrated/verified last time for respective tester.

2.8. Statistics

This function is used to view the statistical calculations for the current open file. These calculations are done in real time and will be updated as new test results are collected.

The Range Parameters permit the recalculation of a specified range of data and the exporting of the results to another file which the operator will be prompted to name and can be located in any folder or drive.


Graph in Statistics shows percentage of Pass, Fail-High, Fail-Low data.




2.9. Print Preview

This function will display the Print preview of test results.

- a. Selected options like *Part Information*, *Result Information*, and *Test Results* etc. in *Print Preview Option* will be included in the preview report. Company Information will be appeared in the preview if the user specify in the settings.




- b. On clicking *OK* Preview window will be displayed. You can navigate the page by clicking next/previous button. And also you can enlarge the preview report by changing the zoom value in drop-down.




2.10. Print

The contents of test results can be printed at any time by choosing Print from toolbar.

- a. Selected options like *Part Information*, *Result Information*, and *Test Results* etc. in *Print Option* will be included in the print file. Company Information will be appeared in the printed file if the user specify same in the *Print option* dialog.




- b. Selecting the appropriate *Include in Report* option display report with respective data.
 Example 1: Report with Part Information, Result Information, Test Results checked.




Note: Same options will be available if the test setup contains Average Group Size > 1.

Example2: Report with Part Information, Result Information, Test Results and X Bar checked.




Example2: Report with Part Information, Result Information, Test Results and Histogram checked.




2.11.Help

Display the *User Guide*, Application and Company information (*About*).



- Select *User Guide* to get user manual.
- Select *About* to get application and company information.




3. Mode of Operations

3.1. Online Mode:

Following steps are required to run the application in online mode.

- Switch ON the hardness device.
- Connect the hardness device to computer.
 - Usually computers (desktop) contain RS232 9 pin port. In this case you can connect directly using the RS232 cable.
 - Computers which don't contain RS232 9 pin port. In this case you can use RS232 to USB converter (Figure 1.4.B). Connect the hardness device to 9 pin of RS232 to USB converter. And connect the USB from "RS232 to USB converter" to computer.
- Check the Hardness device COM port from Device Manager.



- d. Run the DataView application and click on *Communication Setup* from “*Comm Setup*”. Enter the valid port settings and click OK. DataView will run in Online Mode.
- e. In Online mode a green LED appear in bottom right corner of application. In Offline it will be greyed.




- f. Once the connection is established data will be received by DataView and displayed in the main window.

3.2. Offline Mode

You can run the application in Offline mode by selecting Offline from toolbar (see section 2.6 b). Once the application is in offline mode, you can add data manually by clicking *Add* (see 3.3) in main window. All other operations can be performed in offline mode.

3.3. Operations on Test results

You can perform operations like Add, Edit, Remove operations on individual test results.



Add New Test Result

Edit Test Result

Remove Test Result

3.4. Add

Allow user to add hardness reading manually. Clicking on *Add* display a dialog where you can add hardness reading.

- a. If the Group Size is 0 or 1.

Manual Hardness dialog box for Group Size 0 or 1. It features a 'Hardness' input field containing the value '45', a green checkmark icon to its right, and 'Add' and 'Close' buttons at the bottom.

- b. If the Group Size greater than 1.


Manual Hardness dialog box for Group Size greater than 1. It features five input fields labeled 'Hardness1' through 'Hardness5' with values 56, 34, 55, 55, and 56 respectively. Each field has a green checkmark or a red X icon to its right. 'Add' and 'Close' buttons are at the bottom.

In this case Average Group Size is 5. Hence you need to add 5 reading manually at a time.

Note: Add will be enabled only in Offline mode.

3.4.1. Edit

Allow the user to edit existing/stored hardness value. You can edit by selecting the appropriate reading from *History Data* and clicking button *Edit*.



(In case of Average Group Size = 5)

You can also directly edit the value by clicking the appropriate cell in History Data panel.

No	Date Time	HRC	HB30 (Converted)	Status	Testlog Number
8	4/22/2002 5:34:00 PM	45	421	Pass	2D029999
9	4/22/2002 5:35:00 PM	45	421	Pass	2D02NOID
10	4/22/2002 5:36:00 PM	44	409	Pass	2D021234
11	4/22/2002 5:38:00 PM	45	421	Pass	2D021234
12	4/22/2002 5:39:00 PM	55	560	Pass	2D313345
13	4/22/2002 5:41:00 PM	20.3	228	Pass	x
14	4/22/2002 5:42:00 PM	22.6	241	Pass	2D020006
15	4/22/2002 5:42:00 PM	17.4	214	Low	x
16	4/26/2002 11:32:00 AM	100		High	2D030006
17	5/10/2002 2:52:00 PM	58	615	Pass	x
18	5/14/2002 1:35:00 PM	56	577	Pass	2D224646
19	5/15/2002 10:21:00 AM	57	595	Pass	2D222223

3.4.2. Remove and Remove All

You can remove individual or multiple reading by selecting from the History Data and clicking the button *Remove*.

No	Date Time	HRC	HB30 (Converted)	Status	Testlog Number		
<input type="checkbox"/>	8	4/22/2002 5:34:00 PM	45	421	Pass		2D029999
<input type="checkbox"/>	9	4/22/2002 5:35:00 PM	45	421	Pass		2D02NOID
<input type="checkbox"/>	10	4/22/2002 5:36:00 PM	44	409	Pass		2D021234
<input type="checkbox"/>	11	4/22/2002 5:38:00 PM	45	421	Pass		2D021234
<input type="checkbox"/>	12	4/22/2002 5:39:00 PM	55	560	Pass		2D313345
<input type="checkbox"/>	13	4/22/2002 5:41:00 PM	20.3	228	Pass		x
<input type="checkbox"/>	14	4/22/2002 5:42:00 PM	22.6	241	Pass		2D020006
<input checked="" type="checkbox"/>	15	4/22/2002 5:42:00 PM	17.4	214	Low		x
<input checked="" type="checkbox"/>	16	4/26/2002 11:32:00 AM	100		High		2D030006
<input type="checkbox"/>	17	5/10/2002 2:52:00 PM	58	615	Pass		x
<input type="checkbox"/>	18	5/14/2002 1:35:00 PM	56	577	Pass		2D224646
<input type="checkbox"/>	19	5/15/2002 10:21:00 AM	57	595	Pass		2D222223

(No 15 and 16 is selected. Removed on click of *Remove*)

You can also remove all the test results by clicking button *Remove All*.

3.4.3. Adding Note for each hardness

You can add Note for each hardness reading by clicking the respective *Note* cell under History Data Panel.

No	Date Time	HRC	HB30 (Converted)	Status	Testlog Number	Note	
<input type="checkbox"/>	8	4/22/2002 5:34:00 PM	45	421	Pass		2D029999
<input type="checkbox"/>	9	4/22/2002 5:35:00 PM	45	421	Pass		2D02NOID
<input checked="" type="checkbox"/>	10	4/22/2002 5:36:00 PM	44	409	Pass		2D021234
<input type="checkbox"/>	11	4/22/2002 5:38:00 PM	45	421	Pass		2D021234
<input type="checkbox"/>	12	4/22/2002 5:39:00 PM	55	560	Pass		2D313345
<input type="checkbox"/>	13	4/22/2002 5:41:00 PM	20.3	228	Pass		x
<input type="checkbox"/>	14	4/22/2002 5:42:00 PM	22.6	241	Pass		2D020006
<input checked="" type="checkbox"/>	15	4/22/2002 5:42:00 PM	17.4	214	Low		x
<input checked="" type="checkbox"/>	16	4/26/2002 11:32:00 AM	100		High		2D030006
<input type="checkbox"/>	17	5/10/2002 2:52:00 PM	58	615	Pass		x
<input type="checkbox"/>	18	5/14/2002 1:35:00 PM	56	577	Pass		2D224646
<input type="checkbox"/>	19	5/15/2002 10:21:00 AM	57	595	Pass		2D222223

(Adding Note for Hardness No 10 under *Note* cell)



Newage Testing Instruments, Inc.
205 Keith Valley Road
Horsham PA 19044, USA

Tel: 215-355-6900
Fax: 215-354-1803
newage.info@ametek.com

www.hardnesstesters.com

AMETEK Denmark (Scandinavia)
Tel +45 4816 8000 • jofra@ametek.com

Lloyd Instruments Ltd. (UK)
Tel +44 (0) 1243 833 370 • uk-far.general@ametek.com.uk

AMETEK SAS (France)
Tel +33 (0) 1 30 68 89 40 • info.lloyd-instruments@ametek.fr

AMETEK Europe GmbH (Germany)
Tel +49 0 2159 9136 70 • apie@ametek.de

AMETEK Singapore Pvt. Ltd. (Singapore)
Tel +65 484 2388 • aspl@ametek.com.sg